

SOFT SAMPLer

zapojení svorkovnice signálů

		int. 1. bottle
		int. Distributor type
		int. GND
		ext. LEVEL
		ext. LEVEL
		int. Thermo - data
		int. Thermo - +
		int. Thermo - -
		ext. Thermo – data
		ext. Thermo - +
		ext. Thermo - -
		ext. Analog I. - +
		ext. Analog I. - -
		ext. Analog II. - +
		ext. Analog II. - -
option		power on - OPTION
		flow pulses
		event
		disable
		door - option
		GND
		GND
option		thermostat ON
option		sample
option		1. bottle
option		change bottle
option		GND
option		GND

SOFT SAMPLer

schema zapojení 230V AC

